



NOTE:
 WHEN ROLL LOCK IS INSTALLED BRICK MUST BE CUT AWAY SO THAT THE CONDUIT TO THE METER BASE IS A STRAIGHT RUN, OR FUR METER BASE CUT AWAY FROM HOUSE SO THAT CONDUIT WILL BE STRAIGHT (SEE ALTERNATE ROLL LOCK INSTALLATION 2). CONDUIT SHALL NOT HAVE ANY BENDS WHETHER HEATED OR PREFORMED ELBOWS WHEN ENTERING METER BASE. ONLY 270 DEGREES OF BENDS ARE ALLOWED IN ANY UNDERGROUND SERVICE BEING RUN.

METER BASE INSTALLATION GUIDE DRAWING

REVISIONS

DRAWN BY: CJH APPROVED BY: JWM

DATE: 06-07-06 SCALE: NTS



Your Touchstone Energy® Partner

